N 70, Fully-integrated dishwasher, 60 cm S187ECX23G







Optional accessories

The dishwasher with cutlery drawer that's flexible to load and offers the comfort of door opening with a light push.

- $\checkmark\,$ Home Connect Add your dishwasher to your home network and enjoy the infinite possibilities of connected services
- $\checkmark\,$ Flex 2 Baskets Flexible baskets, Rack Matic and Flex Cutlery Drawer offers easy loading solutions
- $\sqrt{}$ Open Dry Automatic door opening during the drying phase for even better drying results
- $\sqrt{}$ Noise Level 42dB Pleasantly quiet at 42dB
- $\checkmark\,$ TimeLight the time remaining in the programme is projected onto the floor

Features

Technical Data

Energy Efficiency Class : D Energy Consumption for 100 cycles Eco Programme : 85 Maximum number of place settings : 14 The water consumption of the eco programme in liters per cycle : 9.5 Programme duration : 4:35 Airborne acoustical noise emissions : 42 Airborne acoustical noise emission class : B Construction type : Built-in Height of removable worktop (mm) : 0 Dimensions of the product (HxWxD) : $815 \times 598 \times 550$ Required niche size for installation (HxWxD) : 815-875 x 600 x 550 Depth with open door 90 degree (mm) : 1150 Adjustable feet : Yes - all from front Maximum adjustability feet (mm) : 60 Adjustable plinth : both horizontal and vertical Net weight (kg): 42.836 Gross weight (kg) : 45.0 Connection rating (W) : 2400 Fuse protection (A) : 10 Voltage (V) : 220-240 Frequency (Hz) : 50; 60 Length of electrical supply cord (cm) : 175 Plug type : GB plug Length inlet hose (cm) : 165 Length outlet hose (cm) : 190 EAN code : 4242004257332 Installation type : Full-integrated





Features

New for 2021

Performance

- Energy Efficiency Class¹: D
- Energy² / Water³: 85 kWh / 9.5 litres
- Capacity: 14 place settings
- Programme duration⁴: 4:35 (h:min)
- Noise level: 42 dB(A) re 1 pW
- Noise Efficiency Class: B
- Noise level (silence programme): 39 dB(A) re 1 pW

Programmes / functions

- 8 programmes: Eco 50 °C, Auto 45-65 °C, Chef 70 °C, Classic 60 °C, Express 45 °C, Glass 40 °C, Silence 50 °C, Favourite
- Default favourite programme: Pre-Rinse
- 4 special options: Remote Start, Extra Dry, Power Zone, Extra Speed
- Easy Clean Programme
- Silence on Demand (via app)

Flexible design elements

- Flex 2 baskets with coloured TouchPoints
- Flex Cutlery Drawer loading on 3rd level
- 3 stage Rackmatic height-adjustable top basket
- Ball bearing wheels on upper basket
- Low friction wheels on bottom basket
- Anti-slip protection strips in upper basket
- Rack Stopper to prevent derailing of bottom basket
- 6 foldable plate racks in top basket
- 6 foldable plate racks in bottom basket
- Upper rack cup shelf
- Lower rack cup shelf
- Glass rack in bottom basket

Innovations and technology

- Home Connect Wi Fi enabled, for dishwasher control
- Open Dry and Heat Exchanger
- Efficient SilentDrive BLDC motor
- DosageAssist detergent dispenser
- DetergentAware
- Aqua and loading sensor
- Neff Sparkle glass care system

Design features

- TouchControl (metallic)
- Push button top controls
- White interior EmotionLight
- Time Light Light projection on the floor
- doorOpen Assist Simple to use, designed for handleless kitchens
- Acoustic end of cycle indicator, remaining programme time indicator on top edge, water fault indicator
- Time delay (3, 6 or 24 hours)
- Childlock when activated double push to open
- Neff AquaStop[®] with guarantee
- Self-cleaning filter system with 3 piece corrugated filter
- Large item spray head, including Steam protection plate
- Stainless steel interior
- Dimensions (HxWxD): 81.5 x 59.8 x 55cm
- ¹ Scale of Energy Efficiency Classes from A to G
- ² Energy consumption in kWh per 100 cycles (in programme Eco 50 °C)
- ³ Water consumption in litres per cycle (in programme Eco 50 °C)
- ^₄ Duration of programme Eco 50 °C

N 70, Fully-integrated dishwasher, 60 cm S187ECX23G



